


1 Elevator IC Card Control System Overview
1.1 System Overview
1.2 System Functions
1.3 System Usage Condition
1.4 System Usage Procedures
2 Usage Description for Products related to Elevator Cabin
2.1 Elevator IC Card Controller Installation
2.2 Enabling IC Card Control and setting up of floor access with controlled or uncontrolled function
2.2.1 COP IC Card Control Enable
2.2.2 Controlled/uncontrolled IC Card Control Function Enable for Individual Floor
2.3 The Usage of IC Card Control Board
2.3.1 Jumper Settings


1.2 5 6 Tm[ )]TJET EMC /Span5 /Span <MCID 42/Lang (en-MY)BDC BT/F3 11.1 0 0/F1 10 56 T.51 Tm[J)4(umpe)4(r)4(S)5(e


1 metre
RF Cable
Thumb
Screw
Front View
Installation Instruction







Property Management Company
Company Cards
B1
Unit 1
1-1
Unit 2
2-1
2-2
Unit 3
edit
delete


Elevator Controller Config
Controller ID: 2
Name: Controller 2
Total Station: 8
Through Door:
Station Display Config:
1 G 2 1A 3 2A 4 3A 5 G 6 1B
7 2B 8 3B
Save


B1
Unit 2
2-1
2-2
Unit 1



Card ID	Owner	Mobile	Householder	Remain	Card Type	Manipulation
CA62BD33	Allen	0430708	Vanke City-B1-Unit 2-2-1	0 Times	User Card	Loss Delete


IC Card Manage
Essential information
Card ID
CA764AE3
Card Type
User
Public
Setting
Owner
Mobile
Household
Country Garden-20#-u 1-1-1
admin
Operation time
2019-01-24 (Overdue)